

Features:

- RF Frequency: 8 - 12 GHz
- Small signal gain: 22.07 dB
- Noise Figure: 1.83 dB
- Output P1dB: 11.04 dBm
- Saturated Output Power: 14 dBm
- DC drain bias voltage: 4 V
- DC supply current: 150 mA
- 0.1um GaAs pHEMT Technology
- Die Size: 1.15 mm * 1.02 mm


Applications:

- Fixed Wireless Broadband
- Microwave Links
- SATCOM
- IoT
- Wi-Fi
- Radar Systems

Deliverables:

- Sample Ready Die
- Product Datasheet

Functional Block Diagram



Pin Configuration

Pin No.	Pin Name	Description
6,8,13,15	GND	Ground
11	VDD1	Drain Bias Voltage 1
10	VDD2	Drain Bias Voltage 2
14	RF-IN	RF Input
7	RF-OUT	RF Output
1,2,3,4,5,9,12,16	N/C	Not Connected

Description:

RFLN12S is a two-stage self-biased Low Noise Amplifier operating from 8–12 GHz, intended for front-end signal amplification in RF receiver systems. The amplifier provides 22.07 dB of small-signal gain, with input and output matched to 50 ohms using an off-chip matching network.

The device is specifically designed for use at 8-12 GHz frequency in fixed wireless broadband, microwave links, WiFi, IoT, and SATCOM, and Radar Systems applications.





The Technology used to design the LNA is a 0.1um GaAs pHEMT Process.

Electrical Specification:



Freq= 8 - 12 GHz, VDD1=VDD2= 4 V, ID= 150 mA, Zo=50 Ω

Parameters	Test Condition	Units	Typ
Gain	8 GHz	dB	22.38
	10 GHz		22.07
	12 GHz		21.38
Output P1 dB	8 GHz	dBm	-
	10 GHz		11.04
	12 GHz		-
OIP3 Pin= 1 dBm Δf = 50MHz	8 GHz	dBm	-
	10 GHz		23.7
	12 GHz		-
Noise Figure	8 GHz	dB	-
	10 GHz		1.83
	12 GHz		-
Input Return Loss	8 GHz	dB	10.48
	10 GHz		14.01
	12 GHz		10.27
Output Return Loss	8 GHz	dB	16.55
	10 GHz		20.18
	12 GHz		12.87
Operating Bias Conditions			
Drain Current (Id)	-	mA	150
Drain Voltage (VDD)	-	V	4


Typical Performance Curves:



Typical Performance Curves:



Application Diagram:



Disclaimer:

Information in this document is provided in connection with Signify RF products. These materials are provided by Signify RF as a service to its customers and may be used for informational purposes only. Except as provided in Signify RF Terms and Conditions of Sale for such products or in any separate agreement related to this document, Signify RF assumes no liability whatsoever. Signify RF assumes no responsibility for errors or omissions in these materials. Signify RF may make changes to specifications and product descriptions at any time, without notice. Signify RF makes no commitment to update the information and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to its specifications and product descriptions. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document.

Contact information:

For the latest specifications, additional product information:

Web: www.signifyrf.com

Email: sales@signifyrf.com

Tel: (+1) 840 356 8957, (+91) 90220 78131, (+91) 84858 41789